

Matte Wallpaper 170 g/m²

Description:

Very high quality inkjet coated non-woven wallpaper. Ideal for personalised interior designs.

Features:

- large gamut and high colour rendering
- smooth surface
- high opacity for good covering
- high dimensional stability and wet strength resistance
- can be applied with standard glue for non-woven wallpaper
- can cover small cracks
- easy to remove
- pvc-free

Specifications:

- 170 g/m²
- non-woven

Applications:

Ideal for personalised interior walls where high resolution reproduction is required.

Care:

The storage of all papers should take place in a recommended climate of 15-25°C, relative humidity of 40 - 60 % and out of direct sunlight.

How to Hang Wallpaper

What you need:

- wallpaper and paste
- large flat work surface
- tape measure and level
- ladder
- drop cloth
- sandpaper, filler, putty knife
- bucket, water, wallpaper paste, sponges, rags
- utility knife or straight edge razor
- smoothing brush
- seam roller
-

1. Prepare the walls:

If you're hanging wallpaper on newly plastered wall, prime the wall first with wallpaper primer to seal the drywall for better adhesion. Wash any dirt or dust from the old walls and sand smooth any bumps or flaked paint. Remove electrical outlet and light switch covers. Fill holes or cracks and allow filler to dry, then sand until smooth.

2. Pick a starting point.

A good place to start and finish wallpapering is in a corner. If you are wallpapering around the whole room, the mismatch where the end meets the starting point is less obvious. Measure out about 850mm from the corner and use a level to lightly draw a vertical straight line on the wall. This will be your guide to line up your first drop which will hang between the corner and the line you have just drawn. You should have about 50mm of excess paper in the corner which will be trimmed off. This is your buffer if the walls are not 100% straight.

3. Apply wallpaper paste.

Lay the wallpaper face down onto a flat surface. Make sure the floor of the room is properly protected with plastic or drop cloths. Apply the paste using a large pasting brush or paint roller, working from the middle to the ends. Be sure that all areas are covered with paste with no unpasted spots. Gently fold the top of the sheet down to the middle so that the pasted sides touch. Next, fold the bottom edge up to the middle. This allows the paste to cure and keep it from drying out. Do not crease the wallpaper. TIP: rather use a little more paste than use too little, it will make lining up the pattern much easier.

4. Hang the wallpaper.

Starting at the ceiling, carefully unfold the top half of the first piece of the wallpaper and gently place the side edge of the strip along the measured line. Don't forget to leave about 50mm of paper at the top and bottom for trimming later. When the strip is in the right position, drop down the bottom half and gently smooth the paper against the wall with your hands, beginning at one edge and working your way across. Use a smoothing brush or damp sponge to smooth out any air bubbles. Use a seam roller to gently smooth down the edges of the wallpaper.

5. Trim the excess paper.

Use a wide-blade putty knife to hold down the top of the wallpaper strip at the ceiling. Use the utility knife to trim the excess wallpaper from the corner, top and bottom. Carefully clean any paste from the ceiling and baseboard. Wipe the strip of wallpaper with a clean, damp sponge to remove any paste and remaining air bubbles.

6. Matching Patterns.

Now the tricky part. If you have non-repeating designs of photographs your wallpaper will be printed with a 50mm repeat. You will notice that all adjacent sheets will share a part of the design. When hanging you will need to make sure that each sheet overlaps the previous sheet by 50mm. If you have enough wallpaper paste you will be able to freely move the paper around until all the elements of the design match up. **VERY IMPORTANT:** Now you will need to use a very sharp utility knife to cut through BOTH pieces of overlapped wallpaper. DO this very carefully, making sure not to tear the wallpaper. Now remove the trimmed paper from beneath and above the wallpaper you have just hung. Use a seam roller to smooth down the edges that should now meet up perfectly. Repeat step 5.

7. Smooth the corners. (For hanging in and around corners)

Your wallpaper will be pre-cut to size so no need to trim them further, just follow the steps 3,4,5 and 6. If your wallpaper design ends in the corner of the room, use a straight edge like a putty knife and push it into the corner. Use it as a guide to cut the wallpaper, working your way down to the bottom. If your wallpaper continues past the corner and around the room then at the corner, make a small slit from the top of the strip to the wall to allow the strip to lay flat at the ceiling. Repeat on the bottom to allow the strip to lay flat at the floor. Trim off the top and bottom and clean the strip.



8. Repeat hanging the strips around the room.

Continue hanging the next strips of wallpaper, taking care to match the pattern, trimming at the ceiling and floor, removing any creases or air bubbles, securing the seams, and cleaning the paste off the paper.

9. Replace light switch and plug plates.

Cut away any paper covering the opening to plugs and light switches.

NOTE: If you are not experienced in D.I.Y we recommend that you obtain the services of a professional wallpaper installer.

PrintWild will not be held liable for damages to the wallpaper furnishings or property during installation or thereafter.